

325/450 CYCLE CHART Elan Control

11/23/10

Pots Pans																		
Fill	Pre-Wash 5:00	Drain	Fill	Pre-Wash 10:00	Drain	Fill	Main Wash 45:00	Drain	Fill	Pre-Rinse 5:00	Drain	Fill	Pre-Rinse 10:00	Drain	Fill	Final - Rinse 33:00	Drain	Dry* 55:00
Normal Wash																		
						Fill	Pre-Wash 5:00	Drain	Fill	Main Wash 25:00	Drain	Fill	Pre-Rinse 12:00	Drain	Fill	Final Rinse 26:00	Drain	Dry* 55:00
Econo Wash																		
			Fill	Pre-Wash 9:00	Drain	Fill	Main Wash 27:00	Drain	Fill	Pre-Rinse 9:00	Drain	Fill	Pre-Rinse 9:00	Drain	Fill	Final-Rinse 27:00	Drain	Dry* 55:00
Light Wash																		
						Fill	Pre-Wash 5:00	Drain	Fill	Main-Wash 25:00	Drain	Fill	Pre-Rinse 6:00	Drain	Fill	Final-Rinse 24:00	Drain	Dry* 55:00
Rinse and Hold																		
						Fill	Rinse 10:00	Drain										

* Only available on the 450 model

OPTIONS

155 Final Rinse

Increases circulation times and temperatures.
Heats final rinse to 155 degrees Fahrenheit.

Top Wash (select models)

Increases circulation times for the upper wash arm.
Decreases circulation times for the lower wash arm.

Econo Dry (select models)

Removes heat from the dry step.
Reduces time in the dry step.

Notes

1. All times are approximate.
2. Circulation times may be extended if incoming water temperature is low.
3. Circulation times may be adjusted and/or fills and drains added based on sensor inputs.
4. All times are for the base cycle with no options selected.
5. Detergent is dispensed in the Wash step of the cycle.
6. Rinse aid is dispensed in the Final Rinse step of the cycle.