



WIRING DIAGRAM VDSC487-6Q

CAUTION- LABEL ALL WIRES PRIOR TO DISCONNECTION WHEN SERVICING CONTROLS. WIRING ERRORS CAN CAUSE IMPROPER AND DANGEROUS OPERATION. VERIFY PROPER OPERATION AFTER SERVICING.

REFER ONLY TO FEATURES WHICH ARE EQUIPPED WITH THIS UNIT.

WARNING- THIS UNIT MUST BE GROUND. SEE INSTALLATION INSTRUCTIONS FOR PROPER GROUNDING PROCEDURES.