



MAIN CONTROL BOARD

WHEN APPLICABLE
CONFIG. 1
21, 23, 27, 29
MODELS

WHEN APPLICABLE
CONFIG. 2
25, 26
MODELS

DISCONNECT POWER CORD BEFORE SERVICING
IMPORTANT - RECONNECT ALL GROUNDING DEVICES

All parts of this appliance capable of conducting electrical current are grounded. If grounding wires, screws, straps, clips, nuts or washers used to complete a path to ground are removed for service, they must be returned to their original position and properly fastened.

IMPORTANT SAFETY NOTICE

This information is intended for use by individuals possessing adequate backgrounds of electrical, electronic and mechanical experience. Any attempt to repair a major appliance may result in personal injury and property damage. The manufacturer or seller cannot be responsible for the interpretation of this information, nor can it assume any liability in connection with its use.

ELECTRICAL SPECIFICATIONS

Temperature Control (Position 5).....	7-(-11)°F
Defrost Control (w/no door openings).....	60hrs @ 45 min
Thermistor kilo-ohm resistance.....	@0°F..... 42.5
.....	@37°F..... 14
.....	@77°F..... 5
Overtemperature Thermostat.....	140-110°F
Defrost Thermistor.....	70°F

NO LOAD PERFORMANCE

Control Position 5/5 and Ambient of 65°F to 90°F	
Fresh Food, °F.....	34 to 40
Frozen Food, °F.....	-3 to 3F
Run Time, % @ 65°F.....	30 to 50
Run Time, % @ 90°F.....	50 to 70

REFRIGERATION SYSTEM

Compressor 21, 23, 25, 26 Models.....	690 BTU/hr
Compressor 27, 29 Models.....	910 BTU/hr
Minimum Compressor Capacity.....	22 inches Hg
Minimum Equalized Pressure	
@ 70°F.....	45 to 48 PSIG
@ 90°F.....	54 to 60 PSIG

REFRIGERANT CHARGE (R134a)

25, 26, 27 models.....	4.50 ounces
21, 23, 29 models.....	4.75 ounces

AIR FLOW

